

JINGLE MINER CONFIGURATION TUTORIAL



For detailed video tutorial, please check out our YouTube channel.

STEP 1



With the Type C cable, then scan the QR code on this page to connect the 'JingleMiner' WIFI.

WiFiManager

JingleMiner

10

Update

STEP 3 After entering this page, you need to edit the following information:

SSID: Current available Wi-Fi name
Password: Available Wi-Fi password

Pool URL: the server address of a mi

Pool party: Fill in according to the URL matches.

the pool. Any mining pool that supports SOLO MINING is OK. The following are the mining pools we recommend: *See more options on the back

URL	PORT
-----	------

btc.zsolo.bid	6057
public-pool.io	21496
pool.vkbit.com	3333

Your BTC address. Available BTC wallet address

TimeZone from UTC: select your current time

For Example:

SSID

jingle

Password

••••••••

☐ Show Password

Pool url

public-pool.io

Pool port

21496

Your BTC address

3CvW4A8a6eLwR5mptan7PvC12E2gMA8P68

TimeZone from UTC (-12/+12)

2


Features

☐ Save mining statistics to flash memory.

Save


Refresh

No AP set




Note: If the page shows zero power, a factory reset is required.
Repeat the above steps to reconfigure by long-pressing the bottom right

Note: If the page shows zero power, a factory reset is required. Repeat the above steps to reconfigure by long-pressing the bottom right



Accessing configuration:
Upon establishing a success


Upon establishing a successful Wi-Fi connection of the Jingle Miner, locate the IP address displayed in the top-left corner of the device's main page. Enter this Jingle Miner IP address into any web browser on your phone or PC to gain access to the web-based management dashboard. Within this interface, you can configure your preferred cryptocurrency lists and define your ideal coin chart period.




Switch Button

Click to switch the screen content in the order of Main page
– 3 Coins Mode – One Coin Mode with a Chart Period


– 3 Coins Mode – One Coin Mode with a Chart Period



Main Page



3 Coins Mode



Conclusions



JINGLE MINER FLASHING TUTORIAL

STEP 1

Sign up and log in
WWW.JINGLEMINER.COM

Click **Web Flasher** on the top menu bar



Connect the miner to your computer,

Click **connect**

Jingle Miner Web Flasher

Connect your device, select your model and board version, and start flashing immediately. No setup required.

Connect

☒ Keep configuration

Start Flashing

Start Logging Download Logs

Connect your device, log the serial data and download it later on.

STEP 2

Select options as following

Disconnect

Jingle Miner

Lottery

300k

☒ Keep configuration

Start Flashing

Start Logging Download Logs

Connect your device, log the serial data and download it later on.

Connected

STEP 3

Start flashing.....

Disconnect

Jingle Miner

Lottery

300k

☒ Keep configuration

Flashing...

Start Logging Download Logs

Connect your device, log the serial data and download it later on.

Flashing progress: 25%

STEP 4

Wait until the flash is successful

Disconnect

Jingle Miner

Lottery

300k

☒ Keep configuration

Start Flashing

Start Logging Download Logs

Connect your device, log the serial data and download it later on.

Device reconnected successfully

Notes

Unlike traditional Pool Mining, Solo Mining allows you to claim the entire block reward individually. For example, a Bitcoin block reward is 3.125 BTC. When you successfully mine a block, you retain the full 3.125 BTC instead of sharing it with others. Compared to Pool Mining, this offers potentially higher returns but is far less predictable—you might earn 3.125 BTC within minutes or wait years for a reward.

Pools for solo mining

If you want to engage in Solo Mining, the mining pool you use must support solo mining; Below are some mining pools that offer solo mining support:

URL	PORT
public-pool.io	21496
pool.nerdminers.org	3333
pool.pyblock.xyz	3333

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator and your body: Use only the supplied antenna.

JINGLE MINER

Product Name:BTC Solo Mini Lottery Miner

Model:Mini Lottery

INPUT:3.3V 300mA 0.99W

FCC ID:2BQGY-MINILOTTERY

This device complies with part 15 of the FCC rules and with ISED Canada's license-exempt RSS(s). Operation is subject to the following 3 conditions:
(1) this device must not cause harmful interference and,
(2) this device must accept any interference received, including interference that may cause undesired operation.
(3) for indoor use only.



Made in China

